



INSTALLATION GUIDE

Single and Dual Gauge Pod Mount for 2022+ Subaru BRZ and Toyota GR86

Installing your single or dual gauge pod mount is detailed below and takes about 15 minutes.



Carefully use an interior trim panel removal kit, a small flathead screwdriver, or a knife to insert in this area of the vent nozzle and dashboard. Gently pry up the vent nozzle and it will release from the dashboard.



Find the square nut in the hardware bag included with your gauge and insert it into the rectangular slot on the bottom of the base.



After inserting the square nut into the slot, then place your gauge pod mount on the vent nozzle as shown above, so it sits flat and is flush with the end of the nozzle.

*Note: Do this part upside down to ensure the square nut stays in place and does not fall out.

Vent shown below on left and middle, is from a Subaru Forester. Process is the same.

small washer with flange screw



With the gauge pod and vent upside down, place the clipped washer, as shown in the center image above. Using the supplied hex key, insert the screw with the small washer on it, into the hole with the square nut and tighten. The clipped washer keeps everything solidly locked in place.