



INSTALLATION GUIDE ScanGauge3 Mount for 2020-2025 Outback


Installing your ScanGauge3 mount is detailed below and takes about 15-20 minutes.



1 Carefully use an interior panel removal kit, a small flathead screwdriver, or a knife to insert in this area of the vent nozzle and dashboard. Gently pry up the vent nozzle and it will release from the dashboard.



Remove the red film from the 3M heavy duty adhesive tape and attach the ScanGauge to the mount.



3 After connecting the data cable to your ScanGauge, there is a hole to run a zip-tie so you can manage the data cable.



4 Place your AB8/AB6 mount on the vent nozzle as shown above. While holding it in place, turn it upside down and use the supplied screw and washers to secure it to the vent nozzle. Reinstall the vent nozzle with the new mount back into the dashboard to complete the installation.

